










Spare parts ST15-S | ST22-HD

Number	Spare parts	Picture	Pieces
1	Motor 1,5 kw ST-19 ST-19-P		1
2	Motor 2.2 kW ST-32		1
3	V-Belt ST-19 ST-19-P ST-32		2
4	Infeed role ST-19 ST-19-P ST-32		2
5	Bearing shaft ST-19 ST-19-P ST-32		2

Number	Spare parts	Picture	Pieces
6	Shaft ST-19 ST-19-P ST-32		1
7	Move knife ST-19 ST-19-P ST-32		2
8	Fix knife ST-19 ST-19-P ST-32		1
9	Timing belt ST-19 ST-19-P ST-32		1